# Introduction of ZEP-series

# ZEON


#### **ZEON CORPORATION**

Specialty Materials Division

The information contained is believed to be reliable, but no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for particular application or the results to be obtained therefrom. The information is based on laboratory work with small-scale equipment and does not necessarily indicate end product performance. Because of the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the products for the application disclosed. Full-Scale testing and end product performance are the responsibility of the user. Zeon Corporation (including its affiliate companies) shall not be liable for and the customer assumes all risk and liability of any use or handling of any materials beyond Zeon Corporation (including its affiliate companies), direct control. The SELLER MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PUPOSE. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without permission of the patent owner.

### **Spin Curve of ZEP series**





#### 【 Dilution Rate 】

•ZEP520A: Dilution Rate 1.0

•ZEP520A-7 : Dilution Rate 1.3


•ZEP520A-2 : Dilution Rate 4.4

#### **Dilution Rate**

={Original Resist(g)+Solvent(g)}/original Resist(g) (Weight Ratio)

#### **Contrast Curve (ZEP520A, ZEP530A)**





Resist	Developer	Eth	γ
520A	N50	81.4	8.1
	N60	108.3	10.0
530A	N50	87.6	8.5
	N60	119.4	11.0

Develop	NXX	Dip	60sec
Rinse	IPA	Dip	10sec

FT: 500 nm

ZEP530A: Lower sensitivity, but higher γ-value ZED-N60: Newest developer


## **Standard conditions for ZEP patterning**

Process	Condition		
Resists	ZEP520A and ZEP530A		
Coating	Spinner		
	300rpm/3sec. X rpm/57sec. FT40nm or 50nm		
Prebaking	180 deg C, 3 min., Hot Plate		
EB irradiation	Equipment : ELS-S50 (ELIONIX CORPORATION)		
	Drawing Field: 100 um X 100 um (50,000 dot X 50,000 dot)		
	Beam Current : 20 pA		
	Accelerating Voltage : 50 kV		
Development	elopment Developer : ZED-N50, ZED-N60, etc.		
	Dipping, 23 deg C, 60 sec.		
Rinse	Rinse Agent : IPA (Isopropyl Alcohol)		
	Dipping, 23 deg C, 30 sec.		

#### Comparison of Pattern Shape at Optimal Exposure Dose confidential ZEON








hp 25nm @FT50nm

## Patterning hp20nm with developer N50






**ZEP530A:** Higher resolution

## Patterning hp20nm with developer N60





**ZEP530A:** Wider dose latitude